



**AMRITA**  
VISHWA VIDYAPEETHAM

# EXPERIMENT REPORT

Measuring and Analysis of Blood Glucose Levels  
using AS7263 NIR Spectroscopy Sensor

**24AIM113 & 24AIM114**

Introduction to NN, CNN and GNN

Analog system design

## Team Members

Group 7

CB.AI.U4AIM24004	ANITRA R
CB.AI.U4AIM24028	NARESH L
CB.AI.U4AIM24029	NIMISHA PATEL
CB.AI.U4AIM24050	YATISH S

**Faculty In-Charge:** Dr. Amruta V & Dr. Snigdhatanu Acharya

# **Measuring and Analysis of Blood Glucose Levels Using AS7263 NIR Spectroscopy Sensor**

## **Objective:**

The objective is to create an experimental setup to try and map the analog output of AS7263's 860nm channel to the corresponding blood glucose level.

## **Pre-Requisites:**

While glucose absorption peaks around 950 nm, there are secondary harmonic oscillations at <850 nm range too.

We will be using the 'W-860 nm' channel of the AS7263 NIR sensor because it has the  $860 \pm 20$  nm wavelength capability and can capture the intensity differences caused to due glucose molecule's secondary harmonic vibrations at the 850 nm range.

## **Experimental Setup:**

### **Apparatus:**

1. Arduino UNO
2. AS7263 NIR spectroscopy sensor
3. 250 mL beaker
4. Weighing scale with a least count of 0.01g (10mg)
5. Glass spatula
6. Glucose
7. Distilled water
8. Non-plastic-coated paper cups


To simulate blood (& glucose), we created ten 100 mL sample glucose solutions marked: 70 mg/dL, 90 mg/dL, 130 mg/dL, 150 mg/dL, 170 mg/dL, 190 mg/dL, 210 mg/dL, 230 mg/dL, 250 mg/dL and 280 mg/dL.

Once we created the sample solutions, we poured each of them in a separate non-plastic-coated paper cup.


## Hardware Assembly:

**Library overview:** Before we got started, we downloaded and installed SparkFun's AS726X Arduino library in the Arduino IDE.

The AS7263 NIR spectroscopy sensor was connected to the Arduino UNO in the following manner:



**Fig. 1: Circuit diagram**



**Fig. 2: Hardware assembly**

## Experiment Assembly:

Once the hardware was assembled, we placed the AS7263 sensor close to the paper cup filled with the glucose solution in such a way that the NIR LED and photodiodes were facing the wall of the cup.

**NOTE:** We discovered that the readings had an improved and consistent accuracy when the sensor was placed ~1cm away from the wall of the cup.




Fig. 3: Experiment assembly diagram




Fig. 4: Experiment assembly

## Code:

The C code was written in Arduino IDE, and the `takeMeasurements()` and `getCalibratedW()` functions from the `AS726X` Arduino library were used to access the W-860 nm NIR channel and get its readings.

```
#include "AS726X.h"
AS726X sensor;

void setup() {
  Wire.begin();
  Serial.begin(115200);
  sensor.begin();
}

void loop() {
  sensor.takeMeasurements();
  if (sensor.getVersion() == SENSORTYPE_AS7262) {
    Serial.print(" Reading: V[");
    Serial.print(sensor.getCalibratedViolet(), 2);
    Serial.print("] B[");
    Serial.print(sensor.getCalibratedBlue(), 2);
    Serial.print("] G[");
    Serial.print(sensor.getCalibratedGreen(), 2);
    Serial.print("] Y[");
    Serial.print(sensor.getCalibratedYellow(), 2);
    Serial.print("] O[");
    Serial.print(sensor.getCalibratedOrange(), 2);
    Serial.print("] R[");
    Serial.print(sensor.getCalibratedRed(), 2);
  }
  else if (sensor.getVersion() == SENSORTYPE_AS7263) {
    Serial.print(" Reading: R[");
    Serial.print(sensor.getCalibratedR(), 2);
    Serial.print("] S[");
    Serial.print(sensor.getCalibratedS(), 2);
    Serial.print("] T[");
    Serial.print(sensor.getCalibratedT(), 2);
    Serial.print("] U[");
    Serial.print(sensor.getCalibratedU(), 2);
    Serial.print("] V[");
    Serial.print(sensor.getCalibratedV(), 2);
    Serial.print("] W[");
    Serial.print(sensor.getCalibratedW(), 2);
  }

  Serial.print("] tempF[");
  Serial.print(sensor.getTemperatureF(), 1);
  Serial.print("]");
  Serial.println();
  delay(10000);
}
```



### **Procedure (for 110 mg/dL sample):**

1. We first weighed out 0.11 grams of glucose (110 mg) in a weighing scale.




**Fig. 5: Measured amount of glucose**

2. We mixed the taken amount of glucose into 100 mL of distilled water in a beaker.
3. A required amount of glucose solution was then poured into the paper cup to fill it.



**Fig. 6: Prepared glucose solution**

4. The sensor was placed close to the paper cup filled with the glucose solution in such a way that the NIR LED and photodiodes were facing the wall of the cup.



**Fig. 7: Sensor placement**

5. Once the sensor was calibrated, we took note of the readings of the W-860 nm channel from the Arduino IDE serial monitor.

```
53   delay(10000);
54   }


Output  Serial Monitor x
Message (Enter to send message to 'Arduino Uno' on 'COM5')

17:20:29.541 -> Reading: R[1.16] S[1.02] T[0.80] U[0.85] V[0.85] W[10.02] tempF[95.0]
17:20:41.187 -> Reading: R[1.16] S[1.02] T[0.80] U[0.85] V[0.85] W[10.02] tempF[95.0]
17:20:52.871 -> Reading: R[1.16] S[1.02] T[0.80] U[0.85] V[0.85] W[10.02] tempF[95.0]
17:21:04.540 -> Reading: R[1.16] S[1.02] T[0.80] U[0.85] V[0.85] W[10.02] tempF[95.0]
17:21:16.210 -> Reading: R[1.16] S[1.02] T[0.80] U[0.85] V[0.85] W[10.02] tempF[95.0]
17:21:27.845 -> Reading: R[1.16] S[1.02] T[0.80] U[0.85] V[0.85] W[10.02] tempF[95.0]
```

**Fig. 8: Serial Monitor output [W: 10.02]**

## Results:

S. No.	Blood Glucose Level	Amount of glucose in 100 mL of distilled water	W-860 nm NIR channel analog output
1	70 mg/dL	0.07 g	10.02
2	90 mg/dL	0.09 g	8.49
3	130 mg/dL	0.13 g	7.79
4	150 mg/dL	0.15 g	7.54
5	170 mg/dL	0.17 g	6.68
6	190 mg/dL	0.19 g	5.97
7	210 mg/dL	0.21 g	4.45
8	230 mg/dL	0.23 g	4.08
9	250 mg/dL	0.25 g	3.68
10	280 mg/dL	0.28 g	2.23





## **Conclusion:**

- i. We have successfully performed the mapping of known glucose samples to output intensity of NIR sensor at W-860 nm channel.
  - ii. Having mapped the two values, we have plotted the values. The points will be further used for curve fitting and neural network training.
-